PURE EPOXY FX-PD8

Only available in Vietnamese market





HIGH LOAD EPOXY ANCHOR

FX-PD8 is solvent-free, two-component pure epoxy chemical anchoring injection system, Used for high performance and critical structural applications.

➤ PRODUCE NAME: Injection Cartridge

(Pure epoxy resin)

➤ PRODUCT CODE: FX-PD8
➤ SIZE: 585ML

➤ RATIO : 3:1

➤ COLOR: PART A-Red

PART B-White

MIXED- Red

> APPROVAL: ETA Option 7 approved. Includes flooded holes.

and wet and dry concrete

conditions.



PRODUCT USAGE

For the fixing of non-expanding anchors in the following:

STRUCTURAL WORK

- √ Rebar / steel reinforcement anchoring in new and refurbishment works.
- √ Threaded rods
- ✓ Bolts and special fastening systems


MECHANICAL AND ELECTRICAL SERVICES INSTALLATION

✓ Anchoring of supports for ducting and equipment.

METAL WORK AND CARPENTRY

- ✓ Fixing of handrails, balustrades and supports.
- ✓ Fixing of railings.
- ✓ Fixing of window and door frames.





PURE EPOXY FX-PD8



UNDERWATER WORK

- ✓ Underwater use.
- ✓ Installation in water-filled drill holes.

For fixing of the following substrates:

- ✓ Concrete
 ✓ Hollow and solid masonry
- √ Hard natural and reconstituted stone
 √ Steel
- √ Solid rock
 ✓ Wood

ADVANTAGES

- ✓ Non-cracked concrete
- lackip Can be uses in damp area lackip
- ☑ Can be used for underwater installation
- ☑ High load capacity
- ☑ Styrene-free

- ✓ Low odor
- ✓ Non-sag, even overhead
- ✓ Non contraction after harden
- ☑ High stability
- ☑ No transportation restrictions











PURE EPOXY FX-PD8



TEST REPORT

PROPERTY APPRAISAL



Test Item	Test Method	Test Result
Compressive Strength (N/mm²)	ASTM D695-15	95.8
Compression modulus (N/mm²)	A51M D070-10	2292
Flexural Strength (N/mm²)	ASTM D790-15ε1	39.5
Flexural modulus (N/mm²)	Procedure Al	5767
Tensile Strength (N/mm²)	ASTM D638-14 (Type I Specimen , 5mm/min)	13.8

TEST OF ANCHORS IN CONCRETE

Pressu	ıre	Destroy Haul Strength (kgf)	Safety Haul Strength (kgf)	· ·	
Concrete St	rength	4000 psi	4000 psi	Hole Diameter	Hole Depth
	#3 (Ф10)	3600	1646	13	90
#4 $(\Phi 13)$ #5 $(\Phi 16)$ No. #6 $(\Phi 19)$ #8 $(\Phi 25)$ #10 $(\Phi 32)$	5760	2879	16	115	
	15080	4570	20	125	
	22920	6708	25	160	
	29586	10749	32	215	
		34431	15046	40	300

^{***} For information only - not for specification purposes.***

PURE EPOXY FX-PD8



TECHNICAL DATA

DENSITY

- > Part A: 1.70 kg/l (±0.5kg)
- > Part B: 1.30 kg/l (±0.5kg)
- ➤ 1.68 kg/l (part A+B mixed) (±0.5kg)

LAYER THICKNESS

> 5 mm max.

SAG FLOW

Non-sag, even overhead, but need to use wedges to fix rebars before curing. One rebar needs two wedges to fix in symmetrical angle.

CURING TIME

Concrete temperature	Minimum curing time in dry concrete	Maximum curing time in dry concrete
+10°C to +15°C	10 hr	48 hr
+15°C to +20°C	150 mins	30 hr
+20°C to +25°C	60 mins	24 hr
+25°C to +30°C	30 mins	15 hr
+30°C to +35°C	15 mins	10 hr
+35°C to +40°C	8 mins	6 hr

Concrete temperature	Minimum curing time in wet concrete	Maximum curing time in wet concrete
+10°C to +15°C	12 hr	72 hr
+15°C to +20°C	180 mins	45 hr
+20°C to +25°C	80 mins	36 hr
+25°C to +30°C	40 mins	20 hr
+30°C to +35°C	20 mins	12 hr
+35°C to +40°C	11 mins	8 hr

PURE EPOXY FX-PD8

Only symilable in Mathematica montret



APPLICATION CONDITIONS / LIMITATIONS

SUBSTRATE & AMBIENT TEMPERATURE

MATERIAL TEMPERATURE

> +10°C min. / +40°C max.

Must be at a temperature of between +10°C and +40°C for application.

DEW POINT

Substrate temperature during application must be at least 10°C above dew point.

STORAGE CONDITION & SHELF-LIFE

- ➤ 24 months from date of production if stored properly in original unopened, sealed and undamaged packaging in cool and dry conditions at temperatures between +5°C and +25°C.
- > Protect from direct sunlight.
- **It is normal that the cured glue material may be discolored by sunlight exposure.**

ORDER INFORMATION

➤ SIZE : 585ml
➤ PART# : FX-PD8

CASE QTY : 12 PCS/ CARTON
▶ PALLET QTY : 90 CTNS/ PALLET

➤ DISPENSING TOOL : WT-296C585

APPLICATION INSTRUCTIONS

> MIXING: Part A: Part B = 3:1 by volume

^{**}All FX-PD8 cartridges have the manufacture date printed on the labels.**

PURE EPOXY FX-PD8



APPLICATION METHOD

STEP1. BORE HOLE DRILLING





> Drilling of hole with an electric drill to the diameter and depth required by the selected reinforcing bar. Drill hole diameter must be in accordance with anchor size

SETTING DETAILS (According ETA-22/0484, Issue 19.07.2022)

Threaded rod installation								
Size	M8	M10	M12	M16	M20	M24	M27	M30
Nominal drill hole diameter Ød0 [mm]	10	12	14	18	22	28	30	35
Cleaning brush diameter [mm]	11	14	16	20	25	30	40	40
Maximum installation torque Tinst, max [N-m]	10	20	40	80	150	200	270	300
Minimum embedment depth hef, min [mm]	60	60	70	80	90	96	108	120
Maximum embedment depth hef, max [mm]	160	200	240	320	400	480	540	600
Minimum edge distance cmin [mm]	40	45	45	50	55	60	75	80
Minimum spacing s _{min} [mm]	40	50	60	75	90	115	120	140
Minimum thickness of member h _{min} [mm]	hef + 30 (≥ 100)			hef + 2·d0				

Rebar installation						
Size	Ø 10	Ø 12	Ø16	Ø 20	Ø 25	Ø 32
Nominal drill hole diameter Ød0 [mm]	14	16	20	25	30	40
Cleaning brush diameter [mm]	16	18	22	30	40	45
Maximum installation torque Tinst, max [N·m]	20	40	80	150	270	300
Minimum embedment depth hef, min [mm]	60	70	80	90	100	128
Maximum embedment depth hef, max [mm]	200	240	320	400	500	640
Minimum edge distance cmin [mm]	45	45	50	65	70	80
Minimum spacing s _{min} [mm]	50	60	80	100	125	160
Minimum thickness of member hmin [mm]	hef + 30 (≥ 100)			hef + 2·d0		







PURE EPOXY FX-PD8




STEP2. BORE HOLE CLEANING



Brush the hole with an appropriately sized wire brush a minimum of two times. If the bore hole ground is not reached with the brush, a brush extension shall be used. The diameter of wire brush is equal to the hole diameter



- Start from the bottom or back of the bore hole, blow the hole clean with compressed air (min. 30 seconds) or an Air machine a minimum of two times. If the bore hole ground is not reached an extension shall be used.
- For bore holes deeper than 200 mm, or bore hole diameter bigger (≥) than 35 mm, compressed air (min. 30 seconds) must be used. Finally blow the hole clean again with compressed air (min. 30 seconds) or an Air machine a minimum of two times. If the bore hole ground is not reached an extension shall be used.



Prior to dispensing into the anchor hole, squeeze out separately the mortar until it shows a consistent red color, and discard non-uniformly mixed adhesive components.

STEP3. BORE HOLE FILLING



Start from the bottom or back of the cleaned anchor hole fill the hole up to approximately twothirds with adhesive. Slowly withdraw the static mixing nozzle as the hole fills to avoid creating air pockets.

STEP4. REBAR / ANCHOR INSERTING



Insert the anchor with a rotary motion into the filled drill hole. Some adhesive must come out of the hole.


**Important: the anchor must be placed within the open time.



PURE EPOXY FX-PD8



STEP5. REBAR / ANCHOR APPLICATION



- > During the resin hardening time the anchor must not be moved or loaded.
 - ** Important: FX-PD8 is an injectable twocomponent epoxy adhesive after installation just wait 7 days cure to meet the required strength in tension and shear from factored load combinations.

HEALTH AND SAFETY INFORMATION

> For information and advice on the safe handling, storage and disposal of chemical products, users shall refer to the most recent Material Safety Data Sheet containing physical, ecological, toxicological and other safety-related data.

FINAL EDITING DATE: 2022/08/11

